


GAME SETTING

Descriptions:

Choose the item witch needs setting, toggle “ON” or “OFF” on setting board to set the items.

There are 8 switches on the main board. Toggle “ON” or “OFF” to change the coin insert number.



Setting items:

DIP SW1		1	2	3	4	5	6	7	8
items									
COIN	1 coins 1 game	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	2 coins 1 game	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
	3 coins 1 game	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
	4 coins 1 game	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
	5 coins 1 game	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
	6 coins 1 game	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
	7 coins 1 game	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF
	8 coins 1 game	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON

Descriptions:

COIN: this setting can decide how many coins player should insert for one game. If set to “1 coin 1 game”, it means insert 1coin for 1 game.